



TEAC

CD-X8

Micro Hi-Fi System

OWNER'S MANUAL





IMPORTANT SAFETY INSTRUCTIONS

- 1) Read these instructions.
 - 2) Keep these instructions.
 - 3) Heed all warnings.
 - 4) Follow all instructions.
 - 5) Do not use this apparatus near water.
 - 6) Clean only with dry cloth.
 - 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
 - 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 - 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
 - 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
 - 11) Only use attachments/accessories specified by the manufacturer.
 - 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
 - 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
 - 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Do not expose this apparatus to drips or splashes.
 - Do not place any objects filled with liquids, such as vases, on the apparatus.
 - Do not install this apparatus in a confined space such as a book case or similar unit.
 - The apparatus draws nominal non-operating power from the AC outlet with its POWER switch in the off position.



WARNING : TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION

- DO NOT REMOVE THE EXTERNAL CASES OR CABINETS TO EXPOSE THE ELECTRONICS. NO USER SERVICEABLE PARTS ARE WITHIN!
- IF YOU ARE EXPERIENCING PROBLEMS WITH THIS PRODUCT, CONTACT TEAC FOR A SERVICE REFERRAL. DO NOT USE THE PRODUCT UNTIL IT HAS BEEN REPAIRED.
- USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

For U.S.A.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the equipment and/or the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


CAUTION

Changes or modifications to this equipments not expressly approved by TEAC CORPORATION for compliance will void the user's warranty.

This product has been designed and manufactured according to FDA regulations "title 21, CFR, chapter 1, subchapter J, based on the Radiation Control for Health and Safety Act of 1968", and is classified as class 1 laser product. There is not hazardous invisible laser radiation during operation because invisible laser radiation emitted inside of this product is completely confined in the protective housings.

The label required in this regulation is shown ①.

① For U.S.A.



Optical pickup:

Type : CMS-M95BG6
Manufacturer : Samsung Electro-Mechanics
Laser output : Less than 0.5 mW on the objective lens
Wavelength : 760 - 800 nm

Contents

Thank you for choosing TEAC. Read this manual carefully to get the best performance from this unit.

IMPORTANT SAFETY INSTRUCTIONS	2
Contents	4
Before Use	4
Specifications	5
Discs	6
Wall Mounting	7
Remote Control Unit	7
Connection	8
Use of Outdoor Antennas	9
Names of Each Control (Front Panel/Remote Control Unit).....	10
Basic Operation	12
Listening to CDs	13
Programmed Playback	15
Shuffle Playback	17
Repeat Playback	17
Listening to the Radio	18
Preset Tuning	19
Setting the Clock	20
Setting the Timer	21
Setting the Sleep Timer	22
Troubleshooting	23

CAUTION

Do not expose this unit to liquids of any kind. Keep any objects containing liquids such as vases, water glasses, potted plants, et cetera off the top of this unit.

Do not install this equipment in a confined space such as a bookcase or similar unit.

Before Use

Read this before operation

- As the unit may become warm during operation, always leave sufficient space around the unit for ventilation.
- The voltage supplied to the unit should match the voltage as printed on the rear panel of the supplied subwoofer. If you are in any doubt regarding this matter, consult an electrician.
- Choose the installation location of your unit carefully. Avoid placing it in direct sunlight or close to a source of heat. Also avoid locations subject to vibrations and excessive dust, heat, cold or moisture.
- Do not place the unit on an amplifier/receiver or any other electronic device that generates heat.
- Do not open the sealed cabinet as this might result in damage to the circuitry or electrical shock. If a foreign object should get inside the unit, contact your dealer or service agency.
- When removing the power plug from the wall outlet, always pull directly on the plug, never yank the cord.
- To keep the laser pickup clean, do not touch it, and always close the CD door.
- Do not attempt to clean the unit with chemical solvents as this might damage the finish. Use a clean, dry cloth.
- Keep this manual in a safe place for future reference.

DO NOT MOVE THE UNIT DURING PLAYBACK

During playback, the disc rotates at high speed. Do NOT lift or move the unit during playback. Doing so may damage the disc or the laser assembly.

WHEN MOVING THIS UNIT

When relocating or packing the unit for moving, be sure to remove the disc. Moving this unit with the disc loaded may result in damage to this unit.

Beware of condensation

When the unit (or a disc) is moved from a cold to a warm place, or used after a sudden temperature change, there is a danger of condensation; vapor in the air could condense on the internal mechanism, making correct operation erratic or impossible. To prevent this, or if this occurs, leave the unit for one or two hours with the power turned on. The unit will stabilize at the temperature of its surroundings.

Maintenance

If the surface of the unit gets dirty, wipe with a soft cloth or use diluted mild liquid soap. Never spray liquid directly on this unit. Apply your cleaner to your cleaning cloth and wipe gently. Be sure to remove any excess completely. Do not use thinner, benzene or alcohol as they may damage the surface of the unit. Allow the surface of the unit to dry completely before using

Specifications

AMPLIFIER section

Output Power (L+R)..... 5W+5W
Output Power (Subwoofer) 15W
Input Sensitivity..... 300mV
Frequency Response..... 50 to 20,000 Hz

TUNER Section (FM)

Frequency Range 87.50 to 108.00 MHz
Sensitivity (S/N30dB) 20dB μ V/m

TUNER Section (AM)

Frequency Range..... 520 to 1710 kHz
Sensitivity (S/N20dB) 54dB μ V/m

CD PLAYER Section

Frequency Response.....20 to 20,000 Hz ($\pm$ 1dB)
Signal-to-Noise Ratio..... 55dB
Wow and Flutter Unmeasurable

SPEAKER SYSTEM Section

L&R speakers:
Type Full range flat type
Impedance..... 4 ohms

Subwoofer:
Impedance..... 8 ohms

GENERAL

Power Requirements 120V, 60Hz
Power Consumption 80 W
Dimension (W x H x D)
Main Unit 6.3" x 8.9" x 3.4"
(160 x 226 x 86 mm)
L & R Speakers 5.5" x 8.9" x 2.4"
(140 x 226 x 61 mm)
Subwoofer 6.3" x 9.2" x 13"
(160 x 234 x 330 mm)

Weight
Main Unit 2.1 lbs (0.96 kg)
L & R Speakers..... 1.3 lbs (0.6 kg) each
Subwoofer 11.7 lbs (5.3 kg)

Standard Accessories

Remote Control Unit (RC-962) x 1
Subwoofer Cable x 1
Speaker Cable x 2
FM Antenna x 1
AM Antenna x 1
Battery for Remote Control x 1
Wall Mount Adaptor x 3
Wall Mount Screw x 10
Tapered Plastic Wall Anchor x 10
Template for Wall Mounting x 1
Owner's Manual x 1
Warranty Card x 1

- Design and specifications are subject to change without notice.
- Weight and dimensions are approximate.
- Illustrations may differ slightly from production models.



trademark of New Transducers Ltd.

Discs that can be played on this unit:

- Commercial audio CD's bearing the "Compact Disc Digital Audio" logo:




- Properly finalized CD-R discs

Note:

- Depending on the quality of the disc and/or the condition of the recording, some CD-R discs may not be playable.
- CD-RW discs cannot be played on this unit.
- Copy-protected discs and other discs which do not conform to the CD standard may not play back correctly in this player. If you use such discs in this unit, TEAC Corporation and its subsidiaries cannot be responsible for any consequences or guarantee the quality of reproduction. If you experience problems with such non-standard discs, you should contact the producers of the disc.

- Always load the disc with the label side facing you. (Compact discs can be played or recorded only on one side.)
- To remove a disc from its storage case, press down on the center of the case and lift the disc out, holding it carefully by the edges.



How to remove the disc




How to hold the disc

- Should the disc become dirty, wipe the surface radially with a soft, dry cloth. Never clean the disc using a circular motion.



- Never use such chemicals as record sprays, antistatic sprays or fluid, benzene or thinner to clean the discs. Such chemicals will do irreparable damage to the disc's plastic surface.
- Discs should be returned to their cases after use to avoid dust and scratches that could cause the laser pickup to "skip."
- Do not expose discs to direct sunlight or high humidity and temperature for extended periods. Long exposure to high temperatures will warp the disc.
- CD-R discs are more sensitive to the effects of heat and ultraviolet rays than ordinary CDs. It is important that they are not stored in a location where direct sunlight will fall on them and which is away from sources of heat such as radiators or heat-generating electrical devices.
- Printable CD-R discs aren't recommended, as the label side might be sticky and damage the unit.
- Do not stick papers or protective sheets on the discs and do not use any protective coating spray.
- Use a soft oil-based felt-tipped pen to write the information on the label side. Never use a ball-point or hard-tipped pen, as this may cause damage to the recorded side.
- Never use a stabilizer. Using commercially available CD stabilizers with this unit will damage the mechanisms and cause them to malfunction.
- Do not use irregular shape CDs (octagonal, heart-shape, etc.). CDs of this sort can damage the unit.



- If you are in any doubt as to the care and handling of a CD-R disc, read the precautions supplied with the disc, or contact the disc manufacturer directly.

Wall Mounting

You can mount the center unit and/or the left and right speakers on a wall.

Option: Attach the supplied adapter brackets.

Precautions

- Be aware that the length of the speaker cable is approximately 10 feet (3 m). Do not attempt to mount the speakers too far from the main unit.
- Drill holes into solid wall support, such as wooden frame or concrete wall.
- As a convenience, a set of tapered plastic anchors is supplied. If you chose to use these anchors, drill a pilot hole using either a 1/4" or 6mm drill bit then tap the anchor into the pilot hole.
Only use these anchors if they are appropriate for the materials onto which the unit is to be mounted. Consult your local hardware store if you are uncertain.
- TEAC supplies these brackets as a convenience to the product owner. Consult your local building codes and exercise all necessary caution when mounting these brackets. If you are unsure how to use the supplied brackets, consult with a local tradesmen or building supply expert.


To hook on the wall

- 1** Use the supplied template to determine drilling points.
- 2** Secure the brackets on the wall.
- 3** Scew the mounting tabs into the brackets.

Note:

Before going on, make connections between the main unit and the speakers by referring to the next page.

- 4** Hang the main unit and/or the speakers to the mounting tabs.




Remote Control Unit

The provided Remote Control Unit allows the unit to be operated from a distance.

When operating the remote control unit, point it towards the remote sensor on the front panel of the unit.

- Even if the remote control unit is operated within the effective range, remote control operation may be impossible if there are any obstacles between the unit and the remote control.
- If the remote control unit is operated near other products which generate infrared rays, or if other remote control devices using infrared rays are used near the unit, it may operate incorrectly. Conversely, the other products may also operate incorrectly.

Battery Installation



- 1** Remove the battery compartment cover.
- 2** Put in the lithium battery (CR2032, 3V).
- 3** Close the cover.


Battery Replacement

If the distance required between the remote control unit and main unit decreases, the battery is exhausted. In this case, replace the battery with a new one.

Precautions concerning batteries

- Do not heat or disassemble batteries and never dispose of old batteries by throwing them in a fire.

Connection




CAUTION

Turn off the power of all the equipment before making connections.
Read instructions of each component you intend to use with this unit.

- Be sure to insert each plug securely. To prevent hum and noise, do not bundle the connection cords with the power cord.

A AM loop antenna

Position the antenna for the best sound.
If you want, you can hook the AM antenna on a wall as shown below:



B FM antenna

While in FM mode, tune in an FM station and extend the lead to find the best position for reception. This antenna may need to be repositioned if you move your unit to a new location.

C Subwoofer

Make the connection between the "TO SUBWOOFER" and "FROM MAIN" sockets using the supplied cable.

D AUX IN

You can connect a DVD player, VCR etc. to this unit.
Connect the component with RCA pin cords.
Make sure to connect the white plug to the white jacks (Left) and the red plug to the red jacks (Right).

E SPEAKERS

Connect the left speaker's plug to L, and the right speaker's plug to R.


- When using speakers other than those supplied with the system, the impedance should be 3 ohms or more.
- Do not connect anything other than speakers to these terminals.

F AC Power Cord



Plug this AC power cord into an AC wall socket.

FM Outdoor Antenna

In an area where FM signals are weak, it will be necessary to use a 75-ohm unbalanced-type outdoor FM antenna using an optional (not supplied) matching transformer connected to an external antenna. Generally, a 3-element antenna will be sufficient; if you live in an area where the FM signals are particularly weak, it may be necessary to use one with 5 or more elements.



Names of Each Control



A POWER

Press this switch to turn the unit on or off (standby).
The main unit is powered via the subwoofer. You need to first turn on the subwoofer.

The equipment draws a nominal amount of power from the AC outlet even with its POWER switch in the OFF position.

B FUNCTION

Use this button to select a source (CD, AUX or TUNER).

C FM/AM

Use this button to select AM or FM.

D Remote Sensor

When operating the remote control unit, point it towards here.

E MEMORY/CLOCK SET

In CD mode, use this button to program tracks.
In TUNER mode, use this button to store preset channels into memory.
This button is also used for clock adjustment.

F REPEAT

In CD mode, use this button for repeat playback.

G STEREO/MONO

In FM TUNER mode, use this button to select stereo or monaural.

H Skip (◀◀ / ▶▶) / TUNING

In CD mode, momentarily press this button to skip tracks.
Hold down this button to search for a part of a track.
In TUNER mode, momentarily press this button to tune in stations.
In Standby mode, these buttons are used to set or adjust the clock and the timer.

I Stop (■)

Use this button to stop playback of CD.

J Play/Pause (▶ / II)

Use this button to start or pause playback of CD.

K CD door

L Display

M VOLUME

Press the up ("+") or the down ("−") button to adjust the volume.

N OPEN/CLOSE

Use this button to open and close the CD door.

O TIMER

Use this button together with the ^ and v buttons to set the timer.

P BASS

Use these buttons to adjust the bass sound up or down.

Q TREBLE

Use these buttons to adjust the treble sounds up and down

R PRESET

In TUNER mode, use this button to select preset stations.

S SLEEP

Use this button to set sleep timer.

T SHUFFLE


Use this button for shuffle playback.

U MUTING

Use this button to mute the sound.

Note:

To simplify explanations, instructions refer to names of buttons and controls on the front panel, making no mention of the use of remote control unit.




1 Press the **POWER** switch on both the subwoofer and the main unit.



2 Select a source by pressing the **FUNCTION** button.




3 Play the source and adjust the volume using the **VOLUME** buttons.



A Muting


To mute the sound temporarily, press the **MUTING** button. Press the **MUTING** button again to restore the sound.




- While muting is engaged, the **VOLUME** level indicators blink.

B Headphones


For private listening, insert the headphones plug into the **PHONES** jack, and adjust the volume using the **VOLUME** buttons. The sound from the speakers is cut off while the headphone jack is inserted.



Listening to CDs 1




1 Press the FUNCTION button to select "CD".



2 Press the OPEN/CLOSE button.



3 Put a disc onto the center spindle of the player with the label side facing you. Press the disc onto the spindle until a slight "click" is heard indicating the disc is mounted correctly.



- Never put more than one disc in the mechanism at a time.
- Ensure that the disc is correctly mounted on the spindle and locked in place.

4 Press the OPEN/CLOSE button to close the CD door.




- It takes a few seconds for the unit to load the disc. No buttons will work during loading. Wait until the total number of the tracks and the total play time of the disc are displayed.
- When no disc is loaded in the CD player, "NO DISC" is displayed.

5 Press the Play/Pause (▶/II) button to start playback.



Playback starts from the first track of the disc.
When the playback of all the tracks has finished, the unit stops automatically.




A To suspend playback temporarily (pause mode)



Press the Play/Pause button during playback. Playback stops at the current position. To resume playback, press the Play/Pause button again.

B To stop playback

Press the Stop button to stop playback.



C To skip to the next or a previous track



During playback, press the Skip button (◀◀ or ▶▶) repeatedly until the desired track is found. The selected track will be played from the beginning.

In the stop mode, hold down the Skip button (or press the button repeatedly) and release it when the track you want to listen to is found. Press the Play/Pause (▶/||) button to start playback from the selected track.


- When the ◀◀ button is pressed during playback, the track being played will be played from the beginning. To return to the beginning of the previous track, press the ◀◀ button twice.
- During programmed playback, the next or previous track in the program is played.

D Search for a part of a track

During playback, hold down the Skip button (◀◀ or ▶▶) and release it when the part you want to listen to is found.



Programmed Playback 1




Up to 64 tracks can be programmed in the desired order.

Shuffle and Repeat functions don't work during programmed playback.

1 Press the FUNCTION button to select "CD".




2 Press the MEMORY button.




"MEMORY" lights up in the display.

- To cancel the program mode, press the STOP button.

3 Press the Skip button (◀◀ or ▶▶) repeatedly to select a track.



4 Press the MEMORY button.



The track is programmed, and "P-02" is displayed.

- Repeat steps 3 and 4 to program more tracks.
- You can program up to 64 tracks.

5 When the selection of track numbers is completed, press the Play/Pause button to start program playback.



- When the playback of all the programmed tracks has finished, or if one of the following buttons is pressed, the MEMORY indicator will go off and the program mode will be cancelled:

STOP, FUNCTION, POWER

The program is retained in memory until the "OPEN/CLOSE" button is pressed or the power is interrupted. You can return to the programmed playback by pressing the MEMORY button and the Play (▶/||) button. (If another source was selected, select the CD mode by pressing the FUNCTION button beforehand.)

To check the programmed order




In the stop mode, press the MEMORY button repeatedly. The track number and program number will be shown on the display.

To add a track to the end of the program


In the stop mode, press the MEMORY button repeatedly until "00" appears on the display. Select a track number using the Skip button (◀◀ or ▶▶) and then press the MEMORY button. The track is added to the end of the program.

To overwrite the program

In the stop mode, press the MEMORY button repeatedly until the program number to be changed appears on the display. Select a new track number using the Skip button and then press the MEMORY button.




To clear program



To clear the programmed contents, press the MEMORY and the STOP button in the stop mode.

- If the OPEN/CLOSE button is pressed, the programmed contents will also be cleared.
- If the unit is disconnected from the power supply, the programmed contents will be cleared.

Shuffle Playback




The tracks can be played randomly. Press the SHUFFLE button during playback or when in the stop mode. "SHUFFLE" will then light up in the display.


- If you press the ►► button during shuffle playback, next track will be randomly selected and played. If you press the ◄◄ button, the currently played track will be played from the beginning. A track cannot be replayed during shuffle playback.
- Shuffle playback doesn't work during programmed playback.
- If one of the following buttons is pressed, shuffle mode will be cancelled:

SHUFFLE, STOP, FUNCTION, POWER, OPEN/CLOSE

Repeat Playback



Every time the REPEAT button is pressed, the mode is changed as follows:



Repeat one track

Press the REPEAT button once during playback. "REPEAT" lights.

The track being played will be played repeatedly. If you press the Skip button and select another track, the track you selected will be played repeatedly.

It is also possible to select a track to be repeated in the stop mode. Press the REPEAT button, select a track using the Skip button (◄◄/►►), and then press the Play/Pause button to start playback.

Repeat all the tracks


All the tracks will be played repeatedly.

Press the REPEAT button twice. "REPEAT ALL" lights.

During programmed playback, programmed tracks will be played repeatedly.

- If one of the following buttons is pressed, repeat mode will be canceled:

STOP, FUNCTION, OPEN/CLOSE, POWER



1 Select "TUNER" by pressing the FUNCTION button.



2 Press the FM/AM button to select a band.



3 Select the station you want to listen to (auto selection).



Hold down the TUNING Up or Down button until the frequency display begins to change. When a station is tuned in, the tuning process will stop automatically.

- Press the Up or Down button to stop the auto selection.

Selecting stations which cannot be tuned automatically (manual selection)

When the Up or Down button is pressed momentarily, the frequency changes by a fixed step. Press the Up or Down button repeatedly until the station you want to listen to is found.

STEREO/MONO button



Pressing this button alternates between Stereo mode and Mono mode.

Stereo:

FM stereo broadcasts are received in stereo and the "STEREO" indicator will light.


Mono:

In weak FM stereo reception areas, select this mode. Reception will now be forced to monaural, reducing unwanted noise.

If the reception is poor

Reposition the AM or FM antenna for the best possible reception. It may also be necessary to connect an external antenna in extremely weak reception areas (see page 9).


Preset Tuning



You can store FM and AM stations into preset channels 1 to 10 respectively.

If the power switch of the subwoofer turned off, the settings kept in memory (clock, preset stations, timer setting) will be erased.

1 Press the FUNCTION button to select "TUNER".




2 Select a band by pressing the FM/AM button.





3 Select the station you want to listen to.



4 Press the MEMORY button.




5 Within 5 seconds, select a preset channel to store the station using the PRESET buttons, and then press the MEMORY button.



The station is stored and the MEMORY indicator goes off. To store more stations, repeat steps **2** to **5**.


How to select preset stations




1 Select a band by pressing the FM/AM button.



2 Press the PRESET button repeatedly until the desired preset station is found.



Setting the Clock



- If the unit is on, press the POWER switch to turn it off.

If the power switch of the subwoofer turned off, the settings kept in memory (clock, preset stations, timer setting) will be erased.


1 Press and hold down the CLOCK SET button.

"12 HOUR" or "24 HOUR" blinks. If you want to change the hour mode, press the ◀◀ or ▶▶ button.




2 Press the CLOCK SET button once more.

The "hour" value blinks.




3 Press the Up or Down button to set the current hour.




4 Press the CLOCK SET button.

The "minute" value blinks.




5 Press the Up or Down button to set the current minute.




6 Press the CLOCK SET button.

The clock starts.




Setting the Timer 1



Adjust the clock before setting the timer.

If the power switch of the subwoofer turned off, the settings kept in memory (clock, preset stations, timer setting) will be erased.


- 1 Press and hold the TIMER button until "TIMER" and "ON" indicators appear on the display.



The "hour" value starts flashing.


- When no button is pressed for 10 seconds, the timer setting mode will be cancelled.

- 2 Press the Up or Down button to set the start time (hour), and then press the TIMER button.




The "minutes" value starts flashing.


- 3 Press the Up or Down button to set the start time (minute), and then press the TIMER button.



"TIMER" and "OFF" indicators appear on the display and the "hour" value starts flashing.




- 4 Press the Up or Down button to set the stop time (hour), and then press the TIMER button.




The "minutes" value starts flashing.


- 5 Press the Up or Down button to set the stop time (minute), and then press the TIMER button.



Setting the Timer 2




6 Press the Up or Down button to select a source (CD or TUNER), and then press the TIMER button.



- Prepare the source. When you select "TUNER", tune in a station.


7 Press the Up or Down button to set the volume, and then press the TIMER button.



The unit will turn on and off at the specified time.


- The timer doesn't work when the unit is turned on manually.
- When you don't use timer, press the TIMER button to turn it off.

Setting the Sleep Timer



Repeatedly pressing the SLEEP button permits setting an interval (from 90 down to 10 minutes) after which you want the unit to automatically turn off and shift into Standby mode.

Each press of the SLEEP button changes the time indication by 10 minutes.



If you have problems with your system, look through this chart and see if you can solve the problem yourself before calling your dealer or TEAC service center.

No power

- ➔ Check the connection to the AC power supply. Check and make sure the AC source is not a switched outlet and that, if it is, the switch is turned on. Make sure there is power to the AC outlet by plugging another item such as a lamp or fan into the outlet.

No sound from speakers.

- ➔ Select the source by pressing the FUNCTION button.
- ➔ Check the connection to the speakers.
- ➔ Adjust the volume.
- ➔ Pull out the headphone's plug from the PHONES jack.
- ➔ If the VOLUME level indicator is blinking, press the MUTING button. (When "CD" is selected, press the PLAY button to start playback.)

The sound is noisy.

- ➔ The unit is too close to a TV or similar appliances. Install the unit apart from them, or turn them off.

Remote control doesn't work.

- ➔ Press the POWER switch to turn the unit on.
- ➔ When the battery has run out, put in a new one.
- ➔ Use remote control unit within the range (15 ft) and point at the front panel.
- ➔ Clear obstacles between the remote control unit and the main unit.
- ➔ If a strong light is near the unit, turn it off.

CD Player

Cannot play.

- ➔ Load a disc with the playback side facing away.
- ➔ If the disc is dirty, clean the surface of the disc.
- ➔ A blank disc has been loaded. Load a prerecorded disc.
- ➔ Depending on the disc, etc. it may not be possible to play back CD-R discs. Try again with another disc.
- ➔ You cannot play back unfinalized CD-R discs. Finalize such a disc in a CD recorder and try again.

Sound skips.

- ➔ Place the unit on a stable place to avoid vibration and shock.
- ➔ If the disc is dirty, clean the surface of the disc.
- ➔ Don't use scratched, damaged or warped discs.

Tuner

Cannot listen to any station, or signal is too weak.

- ➔ Tune in the station properly.
- ➔ Rotate the FM or AM antenna for the best reception position.

Though the broadcast is stereo, it sounds monaural.

- ➔ Press the STEREO/MONO button.

If normal operation cannot be recovered, unplug the power cord from the outlet and plug it again.

If the power switch of the subwoofer turned off, the settings kept in memory (clock, preset stations, timer setting) will be erased.

TEAC

TEAC CORPORATION	3-7-3, Nakacho, Musashino-shi, Tokyo 180-8550, Japan Phone: (0422) 52-5081
TEAC AMERICA, INC.	7733 Telegraph Road, Montebello, California 90640 Phone: (323) 726-0303
TEAC CANADA LTD.	5939 Wallace Street, Mississauga, Ontario L4Z 1Z8, Canada Phone: (905) 890-8008
TEAC MEXICO, S.A. De C.V	Campesinos N°184, Colonia Granjas Esmeralda, Delegacion Iztapalapa, CP 09810, México DF Phone: (525) 581-5500
TEAC UK LIMITED	5 Marlin House, Croxley Business Park, Watford, Hertfordshire, WD18 8TE, U.K. Phone: 01923-819699
TEAC EUROPE GmbH	Bahnstrasse 12, 65205 Wiesbaden-Erbenheim, Germany Phone: 0611-71580
TEAC FRANCE S.A.	17, Rue Alexis-de-Tocqueville, CE 005 92182 Antony Cedex, France Phone: (1) 42.37.01.02
TEAC ITALIANA S.p.A.	Via C. Cantù 11, 20092 Cinisello Balsamo, Milano, Italy Phone: 02-66010500
TEAC AUSTRALIA PTY., LTD. A.B.N. 80 005 408 462	280 Willian Street, Melbourne VIC 3000, Australia Phone: (03) 9672-2400

This appliance has a serial number located on the rear panel. Please record the model number and serial number and retain them for your records.

Model number	Serial number
--------------	---------------